


Model **VXC-1** \_\_\_\_\_


Ser #: \_\_\_\_\_ CO #: \_\_\_\_\_

**VXC-1, USB Cable, Power Supply, Power cord**

Customer: \_\_\_\_\_ Date: \_\_\_\_\_



USB Serial Cable



Notes:

Other: \_\_\_\_\_

**\* ⚠ CAUTION: Refer to the VXC User's Manual for Precautions & Additional Information**  
 Visit [VelmexControls.com](http://VelmexControls.com) to download the VXC User's Manual

**VXC START GUIDE\***

Connect:

- A. AC Cord to DC Power Supply
- B. DC Power Supply to VXC
- C. Motor Cable to Motor
- D. Limit Cable to Limit Switches
- E. AC Power Cord to AC
- F. USB Cable Computer to VXC



Cable Color Code & Axis Name	
Axis #1	White X

- G. Write down Device ID # from tag on motor & Power-up VXC
- H. Download & Run the VXC Utility App from [VelmexControls.com](http://VelmexControls.com)

**Cable Color Code & Axis Name**

Axis #1 White X

**⚠ IMPORTANT: On multi-axis units, tie cables together around connectors or to the base/ motor to reduce stress on connection**



I. Follow setup prompts in the VXC Utility App. If the VXC Utility App connected to & configured the VXC proceed to step J.


- a. If the VXC Utility App is not compatible with your computer, there are other free terminal apps for serial port communication such as TeraTerm (Win PC), CoolTerm (PC,Mac,Linux), Minicom (Mac,Linux). Set these other terminal apps to 57600 baud, 8 data, parity None, 1 Stop, No flow control, Emulate CR+LF. Select the Serial Port the VXC is connected to. To determine which port the VXC is using, disconnect the USB cable from computer, restart the Terminal App and observe which port is now not showing on the list of available ports. When reconnected to the correct Port, test the communication by typing "E" in the terminal (send) window to put the VXC OnLine (yellow LED on VXC will light.) To go Offline type "Q"
- b. If VXC was preconfigured (check in box G above) by Velmex for axes skip step c.
- c. While the VXC is OnLine set each axis to the Device ID of the attached motor(s) with the "setMLH" command.  
**setMLHmM=Device ID # m= Axis/motor# (1,2,3,4)**

Example: If Device ID # for Axis/motor# 1= C,1,0,

Enter: **setMLH1M=C,1,0,**

J. From the VXC Utility App Terminal you can type and send commands directly to the VXC. Type "E" in the Terminal (send) window to put the VXC OnLine (yellow LED on VXC will light.) Type "Q" to take VXC Offline (back to default Jog Mode.) Type "Help" for VXC built-in help menu. Refer the next page of this document for more examples of VXC commands.

## Front (Model VXC-1)



## Jog Mode

When the OnLine (yellow) light is off, the VXC is in the Local/Jog mode. Using the front panel jog buttons, each motor can be jogged a single step or slewed to 2000 sps (5 revs/sec.) in either direction.

When a Jog button is pressed the motor moves 1 step (1/400 rev.) If the button is held for >0.3 second the motor will accelerate to 2000 sps. Pressing Stop or the other Jog button while Jogging will hold the current speed (minimum of 63 sps.)

From the VXC Utility App Terminal you can type and send commands directly to the VXC.

These commands are the most common.

**ImMx**, Set steps to incremental Index motor CW (- is CCW)  $m = \text{motor\# (1,2,3,4)}$ ,  $x = \pm 1$  to  $\pm 16,777,215$

**SmMx**, Set Speed of motor (70% power),  $m = \text{motor\# (1,2,3,4)}$ ,  $x = 1$  to 6000 steps/sec. Default=2000

**C** Clear all commands from currently selected program (program 0 is default)

**E** Enable OnLine mode with echo "on" Use "F" for echo off

**Q** Quit OnLine mode (return to Local/Jog mode)

**R** Run currently selected program (program 0 is default)

**rsm** Run save memory (saves setup/ program values to nonvolatile memory)

Typical commands to enable OnLine, Clear, & Run motor 1 one revolution:


**E C I1M400, R**

To Clear the previous index from the VXC and move the motor back 2 revolutions:

**C I1M-800, R**

Common method to send commands is with commercially available languages and Apps such as BASIC, C, LabVIEW, MATLAB, Python, etc

BASIC, C, Python  
LabVIEW,  
MATLAB, etc.



### CAUTION Refer to the VXC User's Manual for Complete Information

Visit [VelmexControls.com](http://VelmexControls.com) to download the VXC User's Manual

Have a Question? Email us at:  
[Support@Velmex.com](mailto:Support@Velmex.com)

Visit [VelmexControls.com](http://VelmexControls.com) for examples in the different program languages/ Apps

## Common Command Summary\*

### Motion Commands

**ImMx** Set steps to incremental Index motor CW (positive),  $m = \text{motor\# (1,2,3,4)}$ ,  $x = 1$  to 16,777,215

**ImM-x** Set steps to incremental Index motor CCW (negative),  $m = \text{motor\# (1,2,3,4)}$ ,  $x = 1$  to 16,777,215

**IAmMx** Set Absolute Index distance,  $m = \text{motor\# (1,2,3,4)}$ ,  $x = \pm 1$  to  $\pm 16,777,215$  steps

**IAmM0** Index motor to Absolute zero position,  $m = \text{motor\# (1,2,3,4)}$

**IAmM-0** Zero motor position for motor#  $m$ ,  $m = 1,2,3,4$

**ImM0** Index motor until home or positive limit is encountered,  $m = \text{motor\# (1,2,3,4)}$

**ImM-0** Index motor until home or negative limit is encountered,  $m = \text{motor\# (1,2,3,4)}$

**SmMx** Set Speed of motor (70% power),  $m = \text{motor\# (1,2,3,4)}$ ,  $x = 1$  to 6000 steps/sec.

**AmMx** Acceleration/deceleration,  $m = \text{motor\# (1,2,3,4)}$ ,  $x = 1$  to 127.

**(ImMx,I1Mx,)** Run Index moves for axes simultaneously,  $m = 2,3,4$  Axis (Axis 1 must be last)

### Operation Commands

**E** Enable On-Line mode with echo "on"

**F** Enable On-Line mode with echo "off"

**C** Clear all commands from current program

**Q** Quit On-Line mode (return to Local/Jog mode)

**R** Run currently selected program

**N** Null (zero) motors 1,2,3,4 absolute position registers

### Status Request Commands

**Help** Display context sensitive help screen (for use with terminal program interfacing)

**getFac** Get all the logged faults with complete descriptions

**X** Send current position of motor 1 to host (Motor can be in motion)

**Y** Send current position of motor 2 to host (Motor must be stationary)

**Z** Send current position of motor 3 to host (Motor must be stationary)

**T** Send current position of motor 4 to host (Motor must be stationary)

### Program Management Commands

**PMx** Select Program number  $x$ ,  $x = 0$  to 12

**PM-x** Select and clear all commands from Program number  $x$ ,  $x = 0$  to 12

**PM** Request the number of the current Program

**Mem** Request Memory available for currently selected program

**lst** List the current program to host (ASCII text)

**rsm** Run save memory (saves setup & program values to nonvolatile memory)

### Looping & Branching Commands

**L0** Loop continually from the beginning or Loop-to-marker of the current program

**LM0** Sets the Loop-to-marker at the current location in the program

**LM-0** Resets the Loop-to-marker to the beginning of the current program

**Lx** Loop from beginning or Loop-to-marker  $x-1$  times ( $x = 2$  to 65,535)

**L-x** Loop from beginning or Loop-to-marker  $x-1$  times, alternating direction of motor 1

**LAx** Loop Always from beginning or Loop-to-marker  $x-1$  times ( $x = 2$  to 65,535)

**LA-x** Loop Always from beginning or Loop-to-marker  $x-1$  times, alternating direction of motor 1

**Jx** Jump to the beginning of program number  $x$ ,  $x = 0$  to 12

**JMx** Jump to the beginning of program number  $x$  and come back after program  $x$  ends,  $x = 0$  to 12

### Pausing, Input/Output Commands

**Px** Pause  $x$  seconds, ( $x = 0.0001$  to 5.9999 & 6.0 to 6553.5 sec.)

**PAx** Pause  $x$  seconds ( $x = 0.0001$  to 5.9999 & 6.0 to 6553.5 sec, 10  $\mu\text{sec}$  when  $x = 0$ ) Output 1 high for duration of the pause

**U0** Wait for a "low" on user input 1

**U4** User output 1 "low" (reset state)

**U5** User output 1 high

**U90** Wait for a low to high on the Run button or connection I/O,4 with debouncing for a mechanical push-button switch