

## A4007T & A4007TS Turntables Installation and Operation Instructions

1. Loosen the clamping knob, L.
2. Rotate the top disc of the turntable to line up the access holes D with the securing holes B of the bottom disc.
3. Two #10 cap head screws can now be inserted to secure the bottom disc to your base plate.

### Operating Instructions

1. Clamp the turntable in the region desired with the locking knob L.
2. Fine adjust the table with knob K.

A = 10-32 NF-2 thread.

B = Clearance for 10-32 cap head screw

C = 10-32 set screws for internal leveling

D = Access holes to B hole

E = 8-32NF-2Thread

